

Protect your investment and save money with our Water for Life program.







Discounted Replacements



Free Shipping

Contract

CONTACT US TO LEARN MORE 866-662-6885

waterforlife@aguasana.com



The recommended replacement frequency for the AQ-SFRO-REMIN is every 6 months.

Use only certified, genuine Aguasana replacement filters for continued contaminant removal and system performance.



For the full list of contaminants filtered, scan to view the Performance Data Sheet on Aguasana.com.

Aquasana, Inc. 4343 S. Hamilton Road Groveport, OH 43125 866-662-6885 USA 877-332-7873 Canada www.aquasana.com







AQ-SFRO-REMIN

Under Sink Water Filter

SmartFlow™ Reverse Osmosis Remineralizer

REPLACEMENT

Owner's Manual For use with AQ-SFRO

INSTALLATION STEPS

Prepare for Installation


- Turn off COLD water valve and close the water tank valve. Release pressure from system by turning on dedicated faucet until water stops flowing. Once water stops flowing from the dedicated faucet, turn the faucet off.
- 2 Unbox Remineralizer replacement and remove plastic.
- Remove blue tubing from Remineralizer by pushing in the quick connect and pulling tubing out. Slide Remineralizer out of the bracket and discard entire cartridge.





Reconnect Remineralizer

- Place new Remineralizer into the bracket with the label text facing upward.
- **5** Connect blue tubing from system manifold to the top port of the Remineralizer. Then, connect blue tubing from dedicated faucet to the bottom port of the Remineralizer.



Flush and Check for Leaks

NOTE: Do not drink flushed water.

- **6 Open dedicated faucet and tank valve.** Wait for water to stop flowing and then turn off dedicated faucet.
- 7 Turn on cold water valve and allow storage tank to fill with water. While tank refills, carefully inspect for leaks.

NOTE: It will take 1-3 hours for the water tank to refill.

8 Once the water tank is full again, turn on the dedicated faucet to empty tank. After the tank is empty, turn off the faucet and allow tank to refill. Repeat this step 2 more times. Once the tank has refilled for the fourth time, the system is ready to use.

NOTICE – Safeguards: If you are experiencing a tubing connection leak, shut off COLD water, disconnect and re-set the tube.

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

