

This system is designed and tested for use with genuine Aquasana parts including replacement tanks, media and all hardware. Use of parts from other manufacturers may result in loss of contaminant reduction performance, system damage or failure. Use of parts from other manufacturers will also void your warranty. Please visit www.aquasana.com for all replacement parts.

**THIS UNIT MUST BE INSTALLED BY A
LICENSED PLUMBER TO VALIDATE THE WARRANTY.**

**This product is not intended for use with water that is
microbiologically unsafe or of unknown quality without
adequate disinfection before or after the unit.**



COMPONENTS

- EQ-AS20 unit
- EQ-AS20R
- Installation Instructions
- (2) 3" PVC Nipples
- (2) Sch.80 PVC Unions
- (1) Wrench
- (1) Bracket

Installation Instructions

EQ-AS20 Aquasana SimplySoft for Tankless Water Heaters

Precautions & Operating Specifications

- Read all precautions, installation, and operating instructions carefully and completely before installing the unit.
- Do not install this filter where the line pressure may exceed 100 psi. Operating pressure range: 20 psi – 100 psi.
- The rated service flow is 7 gallons per minute; rated capacity is 2 years. Replacement unit is available at aquasana.com.
- Install on cold water lines only. Operating temperature range: 40° – 90°F. Protect unit from freezing.
- Do not install the unit on its side or in direct sunlight. KEEP THE UNIT IN AN UPRIGHT POSITION AT ALL TIMES.
- Filter installation must comply with state and local plumbing codes.
- Cleaning: use only warm, soapy water to clean the outside of the housing. Rinse well with fresh, clean water. Never use chemical cleaning products on the filter's exterior surface because they may damage the filter housing.

INSTALLATION

1. Turn off water main.
2. Install the unit to the main water supply using the supplied components.
3. The SimplySoft unit must be firmly braced and supported with the bracket provided.
4. Once installation is complete, slowly turn the water on and inspect for leaks.
5. Slowly open the water faucet closest to the installed unit and allow water to run for 5-10 minutes for the final flushing period.

Important:

Do not over tighten fittings, as this may cause leakage and broken fittings. Do NOT use pipe dope. The use of pipe dope voids the warranty. You may use NSF-certified pipe primer, glue and plumber's tape. Leave two-three threads exposed and do not exceed seven layers of plumber's tape. More than seven layers will cause the nipple to crack and leak.

Installation Diagram

